

Packster 40 CARRY SYSTEM (VBK0188)

The optional Carry System makes luggage transport convenient.

State: 12.04.2019 15:43:00

Scope of delivery

- 1x front plate 180170 incl. Velcro and Grip tape
- 1x bottom plate 180271, incl. grip tape
- 1x upper rail
- 1x lower rail incl. plugs
- 2x long stay incl. plastic studs
- 2x short stay
- 1x shroud Carry System
- 4x countersunk screw (Torx M5 x 16 DIN 965 A2)
- 9x countersunk screw (Torx M5 x 25 DIN 965 A2)
- 4x countersunk screw (Torx M5 x 30 DIN 965 A2)
- 1x countersunk screw (Torx M5 x 40 DIN 965 A2)
- 6x rounded head bolt (allen M 5 x 20 mm ISO 7380 A2)
- 4x rounded head bolt (allen M 5 x 25 mm ISO 7380 A2)
- 2x rounded head bolt (Torx M 5 x 12 mm ISO 14583 A2)
- 6x plastic spacer 6x15x5
- 6x spacer flat-round
- 3x washer (d = 5,3 mm DIN 134 A2)
- 14x selflock nut M5 with flange

Assembly

1. Put 4 plastic spacer 6x15x5 ^① in place (fig. 1).
2. Put bottom plate in place and fix it with 5 bolts M5x25 ^③ and 5 nuts ^④ (fig. 2).



fig. 1: Grip tape and spacer




fig. 2: bottom plate

Datei: VBK0188-P40-carry-I71106.docx

State: 12.04.2019 15:43:00

3. Mount bolt M5x40 ^①, plastic spacer 5x20x3 ^⑥, washer ^⑦ and nut ^④ (fig.3).
4. Put 2 plastic spacers 6x15x5 ^② in place. Mount front plate ^⑧ with 4 bolts M5x25 ^③ and 4 nuts ^④ (fig. 4).
5. Connect lower rail ^⑧, 2 long stays (plastic stud ^⑨ up forward) and 2 short stays ^⑩ by 4 countersunk screws M5x30 ^⑪ (fig. 5). Do not tighten bolts yet.
6. Connect upper rail ^⑫ and stays by 4 rounded head bolts M5x25 ^⑬ (fig. 5). Tighten all bolts.
Tightening torque 3-4 Nm.
7. Connect lower rail to bottom plate by 6 countersunk screws M5x20 and spacers flat-round ^⑭ (fig. 6).
Attention: insert bolts straight and carefully. **Tightening torque 3-4 Nm.**
8. Connect upper rail by 2 rounded head bolts M5x12 and washer ^⑮. Connect upper rail to front plate by 4 countersunk screws M5x16 and nuts ^① (fig. 6). **Tightening torque 4-5 Nm.**
9. Apply shroud and fix it by its velcro belts (fig. 7).




fig. 3: bolt M5x40




fig. 4: front plate




fig. 5: rail assembly




fig. 6: mount rail



fig. 7: apply shroud

Datei: VBK0188-P40-carry-I71106.docx


Carry System use

Before each ride the following items must be checked:

- The luggage must be fixed securely and nothing should get caught by the wheels.
- The maximum loading capacity of the Carry System is 60kg. The maximum load of the E-Bike shall not exceeded.
- Any kind of modification at the Carry System is prohibited.

 **WARNING**

Luggage can loosen if not fixed securely and may cause heavy accidents!

 When riding with a full load, the handling is affected and it takes longer to stop.

➔ Be sure to make some handling and braking test prior to heading into traffic.

Informations for use

- Wood is a working material. So check the tight bolt connections on a regular base.
- If the Packster is exposed to humid conditions, we recommend to apply wood protective oil at all blank edges.